



# Get the Answers You Need.

[« Back](#)

## Before You Sign Up

## Getting Started

## Video Phone Support

## Phone Adapter Support

## Documentation

## Contact Customer Care

### Digital Photo Frame

#### View Images

- Insert a USB Drive into the back of your video phone or insert a SD Card into the side of your video phone. Press MENU, select Digital Photo Frame and press OK.
- Select View Another Picture and choose to view your photos either from a USB drive or SD Card. Scroll through the pictures on your device by selecting Previous Picture or Next Picture. Select the photo you want to see and press OK.

#### Setup Digital Photo Frame

- From the Main Menu, select Settings and then System Settings. Next, select Display.
- Scroll down to Digital Photo Frame and select ON, then change the Digital Photo Frame Delay to your desired speed to 10, 15 or 20 seconds. Press BACK and save your changes.

[User Manual](#)*images are simulated*

### Digital Photo Frame FAQ

- [Can I display my pictures by connecting a USB flash drive to the video phone's USB port?](#)
- [Can I remove my USB or SD card and add other pictures?](#)
- [Will I be able to retrieve my pictures once I remove my SD or USB device and reinsert it?](#)
- [When I have a USB flash drive and a SD card inserted, which one will store the pictures I save? Also, which one will the IRIS 3000 use to pull pictures?](#)
- [My USB or SD card has multiple folders. How do I know where my saved pictures are stored when I capture them?](#)
- [How will I know when my USB or SD card is ready for use?](#)
- [I have my USB card in the back of my device. When I try to take pictures, it says no storage device found. What does this mean?](#)

#### Can I display my pictures by connecting a USB flash drive to the video phone's USB port?

Yes. The phone's USB port allows you to connect a USB flash drive and download your JPEG photos. ACN is also working on future enhancements to allow users to connect USB external hard drives and other devices.

[Back to Top](#)

#### Can I remove my USB or SD card and add other pictures?

Yes. The pictures you display come directly from your USB or SD card. When you remove the USB flash drive or SD card, the phone no longer has access to them, allowing you to replace them with photos from other storage devices.

[Back to Top](#)

**Will I be able to retrieve my pictures once I remove my SD or USB device and reinsert it?**

Yes. We recommend you do not remove the storage device during a call as it may interrupt it.

[Back to Top](#)

**When I have a USB flash drive and a SD card inserted, which one will store the pictures I save? Also, which one will the IRIS 3000 use to pull pictures?**

Pictures are downloaded from the storage device you indicate in the internal settings. Please reference the IRIS 3000 User Manual for instructions on storage device configuration.

[Back to Top](#)

**My USB or SD card has multiple folders. How do I know where my saved pictures are stored when I capture them?**

A folder called 'IRIS 3000' is automatically created when a picture is saved.

[Back to Top](#)

**How will I know when my USB or SD card is ready for use?**

You should receive an on-screen display (OSD) stating "MOUNTING SD" or "MOUNTING USB". This display will be brief.

[Back to Top](#)

**I have my USB card in the back of my device. When I try to take pictures, it says no storage device found. What does this mean?**

If there is both a USB and SD device connected, the phone will only save to one of the two devices (SD is the default device).

[Back to Top](#)

***Important 911 and E911 Notice***

---

[Privacy Policy](#) [Terms & Conditions](#) [Acceptable Use Policy](#) [Support](#) [Site Map](#) [ACN Digital Home](#) [MyACN for Reps](#) [MyACN Home](#)

Copyright 2009, ACN Inc. All rights reserved.